

## Greater New York Programming Contest

Rutgers University Piscataway, NJ



# **D • Decoding EDSAC Data**

The world's first full-scale, stored-program, electronic, digital computer was the EDSAC (<u>E</u>lectronic <u>D</u>elay <u>S</u>torage <u>A</u>utomatic <u>C</u>alculator). The EDSAC had an accumulator-based instruction set, operating on 17-bit words (and 35-bit double words), and used a 5-bit teletypewriter code for input and output.

The EDSAC was programmed using a very simple assembly language: a single letter opcode followed by an unsigned decimal address, followed by the the letter 'F' (for *full word*) or 'D' (for *double word*). For example, the instruction "A 128 F" would mean "add the full word at location 128 to the accumulator", and would be assembled into the 17-bit binary value, 1110000010000000, consisting of a 5-bit opcode (11100 = "add"), an 11-bit operand (00010000000 = 128), and a single 0 bit denoting a *full word* operation (a 1 bit would indicate a *double word* operation).

Although arithmetic on the EDSAC was *fixed point two's complement binary*, it was not mere integer arithmetic (as is common with modern machines). The EDSAC hardware assumed a *binary point* between the leftmost bit and its immediate successor. Thus the hardware could handle only values in the range -1.0 <= x < 1.0. For example:

Value	Binary Representation
-1.0	1000000000000000
1/2	0100000000000000
3/4	01100000000000000
-1/2	11000000000000000

As you can see, the largest possible positive value was:

and the smallest possible positive value was:

(This also happens to be the increment between successive values on the EDSAC).

By a curious coincidence (or an elegant design decision), the opcode for the *add* operation (11100) was the same as the teleprinter code for the letter 'A'. The opcode for *subtract* was the same as the teleprinter code for 's' (01100), and so on. This simplified the programming for the assembler (which, incidentally, was a mere 31 instructions long). The EDSAC teleprinter alphabet was "PQWERTYUIOJ#SZK\*?F@D!HNM&LXGABCV" (with 'P' = 00000, 'Q' = 00001, and so on, up to 'V' = 11111).

Unfortunately, the EDSAC assembler had no special directives for data values. On the other hand,



## Greater New York Programming Contest

Rutgers University Piscataway, NJ



Your job is to write a program that will translate EDSAC instructions into the appropriate decimal fractions.

### Input

The first line of input contains a single integer P,  $(1 \le P \le 1000)$ , which is the number of data sets that follow. Each data set is a single line that contains N (the dataset number), followed by a space, followed by an EDSAC instruction of the form:  $c\Box d\Box s$ , where c is a single character in the EDSAC alphabet, d is an unsigned decimal number  $(0 \le d \le 2^{11})$ , and s is either a 'D' or 'F'. Note:  $\Box$  represents a single space.

#### Output

For each data set there is one line of output. It contains the data set number (*N*) followed by a single space, followed by the exact decimal fraction represented by the by the EDSAC instruction, including a minus sign (for negative values). The format for the decimal fraction is: sb.ddd..., where s is an optional minus sign, b is either a 1 or 0, and d is any decimal digit (0-9). There must be at least 1 and at most 16 digits after the decimal point. Trailing zeros in the fraction *must* be suppressed.

Sample Input	Sample Output
13	1 0.0
1 P 0 F	2 0.5
2 I 0 F	3 -0.5
3 & 0 F	4 -1.0
4 ? 0 F	5 0.0999908447265625
5 Q 1228 D	6 0.0000152587890625
6 P 0 D	7 -0.0000152587890625
7 V 2047 D	8 0.9999847412109375
8 * 2047 D	9 -0.9999847412109375
9 ? 0 D	10 0.0078125
10 P 256 F	11 -0.015625
11 V 1536 F	12 0.3333282470703125
12 T 682 D	13 0.31414794921875
13 T 54 F	